



**NOTE:** INSTALL TRACER WIRE FULL LENGTH OF PIPE. 18 GAUGE INSULATED COPPER WIRE. WHEN CONNECTING TO EXISTING TRACER WIRE, USE A WATER TIGHT WIRE CONNECTOR OR INSTALL C.O WITH BOTH ENDS OF TRACER WIRE CLEARLY EXPOSED ABOVE FINISHED GRADE.



**ROGUE VALLEY  
SEWER SERVICES**

138 WEST VILAS ROAD, CENTRAL POINT, OR.

PRESSURE SANITARY SEWER TERMINAL FLUSHING PORT

Rev. -  
Rev. -

STANDARD  
DRAWING  
NO. 10-2  
DATE: 07/18